

Product Name: **CABINET LIGHT**

---

The products listed contains a light source of energy efficiency class:



XCUCCL 3 / 5 / 8 / 14 / 16 NW




XCUCCL 3 / 5 / 8 / 14 / 16 WW


---

## Disassembly Instructions:

1. Ensure power is off prior to disassembly.
2. Remove power cable.
3. Disconnect male and female cable.
4. Undo Terminations.
5. Dislodge fitting from mounting clips.
6. Unscrew mounting clips
7. Remove end caps.
8. Slide gear tray out.
9. Unscrew all visible screws and nuts to segregate all component parts.



Replaceable (LED only) light source by a professional



Non - replaceable control gear